

Safety Warnings



The lightning flash arrowhead within an equilateral triangle is intended to alert the user to the presence of non insulated, 'dangerous voltage' within the product's enclosure, that may be of sufficient magnitude to constitute risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying this product.



CAUTION:
This symbol indicates that the marked item may be Hot and should not be touched without proper care.

- To minimise the risk of burns and other injuries to children, position the device such that hot surfaces are out of their reach.
- To minimise the risk of fire, keep flammable materials like paper and cloth (for example, curtains) away from the hot surface.



WARNING:
Do not expose this apparatus to dripping or splashing liquids, and ensure that no objects filled with liquids – such as vases – are placed on the apparatus. **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

WARNING

DO NOT OPEN

TO PREVENT THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE SPEAKER COVERS (OR BACKS).
NO USER-SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

AVISQUE

POUR EVITER TOUT RISQUE DE CHOC ELECTRIQUE,
NE PAS DEMONTER LE COUVERCLE DU HAUT PARLEUR.
AUCUN ENTRETIEN DES PIECES INTERIEURES N'EST REQUIS.
TOUT SERVICE D'ENTRETIEN NE DOIT ETRE EFFECTUE QUE
PAR DU PERSONNEL D'ENTRETIEN QUALIFIE.

CAUTION:

TO PREVENT THE RISK OF ELECTRIC SHOCK, MATCH WIDE
BLADE OF PLUG TO WIDE SLOT. INSERT CAREFULLY.
ATTENTION:
POUR EVITER LES CHOCES ELECTRIQUES, INTRODUIRE LA
LAME LA PLUS LARGE DE LA FICHE DANS LA BORNE
CORRESPONDANTE DE LA PRISE ET POUSSER JUSQU'AU
FOND.

READ AND HEED IMPORTANT SAFETY WARNING ON REAR OF SPEAKER ENCLOSURE

Warranty and Technical Support

- Please refer to the enclosed Technical Support leaflet.
- Veuillez vous reporter ci-jointe à la brochure concernant le supporte technique.
- Bitte beziehen Sie sich auf das beiliegende technische Begleitbuch.
- Consultare il depliant allegato contenente informazioni sull'assistenza tecnica.
- Consulte el folleto incluido de Asistencia Técnica.
- Zie de bijgevoegde instructies voor informatie over de technische dienst.
- Consulte o folheto de Assistência Técnica incluído.
- Vedlagt finner du en veiledning om kundestøtte.
- Katso tuotteen mukana tullutta Tekninen tuki -lehtistä.
- Var god se den bifogade Tekniska support handboken.
- Se den vedlagte tekniske support brochure.
- Prosim, seznajte se s letákem technické podpory.
- Proszę zapoznać się z załączoną broszurą Pomoc Techniczna.
- См. прилагаемый листок Техническая поддержка.
- Olvassa el a mellékelt Technikai segítőanyagját című lapot.
- Ανατρέξτε στο εσώκλειστο φυλλάδιο Τεχνικής υποστήριξης.



With its five compact satellite speakers and separate subwoofer with 6-channel amplification, the Creative GigaWorks ProGamer G500 is an excellent speaker system for use with Creative EAX®-enabled products. Combine it with the powerful Sound Blaster Live! family or the innovative Sound Blaster Audigy series audio cards, and experience a thrilling, high-quality 5.1 PC home theater audio experience that meets the prestigious THX® multimedia certification standard. For more information on EAX, be sure to visit www.EAX.creative.com.

CREATIVE®



CREATIVE
GIGAWORKS™
PROGAMER G500

July
© 2005 Creative Technology Ltd. All rights reserved. The Creative logo, GigaWorks, CMSS, Sound Blaster, the Sound Blaster logo, the EAX logo, EAX, Flared DynaPort and PowerTouch are registered trademarks or trademarks of Creative Technology Ltd. in the United States and/or other countries. THX and the THX logo are trademarks or registered trademarks of THX Ltd. Used under authorisation. All other logos, brand or product names are trademarks or registered trademarks of their respective holders and are hereby recognised as such. All specifications are subject to change without notice. Use of this product is subject to a limited warranty. Actual contents may differ slightly from those pictured.

P/N 03MF404000001 Rev. A

EN Quick Start Guide

FR Démarrage Rapide

DE Schnellstart

IT Guida Quick Start

ES Guía Rápida

NL Snel aan de slag

PT Início Rápido

NO Lynstart

FI Pikaohje

SV Snabbstart

DA Lynstart

CZ Krátký Úvod

PL Szybki start

RU Краткие указания

HU Gyorskialauz

EL Οδηγός γρήγορης εκκίνησης

Important Safety Instructions

READ INSTRUCTIONS - All safety and operating instructions should be read before the Creative GigaWorks ProGamer G500 amplified subwoofer/satellite system is operated.

RETAIN INSTRUCTIONS - The safety and operating instructions should be retained for future reference.

HEED WARNINGS - All warnings on the subwoofer and in the operating instructions should be adhered to.

FOLLOW INSTRUCTIONS - All operating and usage instructions should be followed.

CLEANING - Unplug the subwoofer from the wall outlet or other power source before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a dry cloth for cleaning.

ATTACHMENTS - Do not use attachments not recommended by Creative Technology as they may cause hazards.

WATER AND MOISTURE - Do not use the subwoofer near water - for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.

ACCESSORIES - Do not place the Creative GigaWorks ProGamer G500 system on an unstable cart, stand, tripod, bracket, or table. The subwoofer or satellites may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by Creative Technology, or sold with the product. Any mounting of the satellites or subwoofer should follow the manufacturer's instructions, and should use a mounting accessory recommended by Creative Technology.

VENTILATION - Slots and openings in the cabinet are provided for ventilation, to ensure reliable operation of the subwoofer and to prevent it from overheating; and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. The subwoofer should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or Creative Technology's instructions have been adhered to.

HEAT - The subwoofer should be situated away from heat sources such as radiators, heat registers, stoves, and other products (including amplifiers) that produce heat.

POWER SOURCES - The subwoofer should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power or other sources, refer to the operating instructions.

POLARISATION - The subwoofer may be equipped with a polarised alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarised plug.

POWER-CORD PROTECTION - Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the subwoofer.

LIGHTNING - For added protection for the Creative GigaWorks ProGamer G500 system during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet. This will prevent damage to the subwoofer due to lightning and power line surges.

OVERLOADING - Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

OBJECT AND LIQUID ENTRY - Never push objects of any kind into the subwoofer through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the subwoofer.

SERVICING - Do not attempt to service the subwoofer your self as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

DAMAGE REQUIRING SERVICE - Unplug the subwoofer from the wall outlet or other power source and refer servicing to qualified service personnel under the following conditions:


- a) When the power-supply cord or plug is damaged.
- b) If liquid has been spilled, or objects have fallen into the subwoofer.
- c) If the subwoofer has been exposed to rain or water.
- d) If the subwoofer does not operate normally by following the operating instructions; or exhibits a distinct change in performance.
- e) If the product has been dropped or damaged in any way.

REPLACEMENT PARTS - When replacement parts are required, be sure the service technician has used replacement parts specified by Creative Technology, or have the same characteristics as the original part. Unauthorised substitutions may result in fire, electric shock, or other hazards.

SAFETY CHECK - Upon completion of any service or repairs to the Creative GigaWorks ProGamer G500 system, ask the service technician to perform safety checks to determine that the Creative GigaWorks G500 system is in proper operating condition.

WALL OR CEILING MOUNTING - The Creative GigaWorks ProGamer G500 satellites should be mounted to a wall or ceiling only as recommended by Creative Technology.

- (Optional) Rear satellite floor stands are sold separately. For more information, please refer to <http://www.europe.creative.com>
- (Facultatif) Des socles pour haut-parleurs satellites arrières sont disponibles séparément. Pour plus d'informations, visitez notre site Web à l'adresse <http://www.europe.creative.com>
- (Zusätzlicher) hinterer Satelliten Bodenständer werden separat verkauft. Mehr Informationen erhalten Sie unter <http://www.europe.creative.com>
- (Opzionale) I piedistalli per i satelliti posteriori sono venduti separatamente. Per ulteriori informazioni, per favore fare riferimento all'indirizzo <http://www.europe.creative.com>
- (Optional) Puede adquirir por separado soportes para los altavoces traseros. Para más información, visite nuestro sitio en <http://www.europe.creative.com>
- (Optioneel) Satellite steunen voor de achter satellieten worden apart verkocht. Voor meer informatie, gelieve u te richten tot <http://www.europe.creative.com>
- (Optional) Suportes de satélite traseiros poderão ser adquiridos separadamente. Para mais informações, por favor consulte o nosso Web site <http://www.europe.creative.com>
- (Valgfritt) Gulvstativ til bakre høyttalere selges separat. Besøk vårt Web-område <http://www.europe.creative.com> hvis du vil ha mer informasjon
- (Lisävaruste) Takasatelliittikaiuttimien jalustat myydään erikseen. Lisätietoja Internet-sivoltteesta: <http://www.europe.creative.com>
- (Tillbehör) Ställningar för bakre satellit högtalare säljs separat. Mer information hittar du på vår webbplats <http://www.europe.creative.com>
- (Ekstraudstyr) Stativer til baghøjttalere sælges separat. For mere information, se venligst <http://www.europe.creative.com>
- (Voliteľná) Stojany zadných satelitných reproduktorů. Podrobnosti najdete na našom webovom serveru <http://www.europe.creative.com>
- (Opzionale) Stativy do týchto glosníkov satelitnýchych sprádzavane są osobno. Więcej informacji na ten temat można znaleźć na <http://www.europe.creative.com>
- (Необязательно) Подставки для задних сапелитных громкоговорителей продаются отдельно. Дополнительные сведения приведены на веб-узле по адресу <http://www.europe.creative.com>
- (Opzionale) A hátsó szatellit hangfalak állványait külön kell megvásárolnia. Ha további információra van szűksége, keresse fel a <http://www.europe.creative.com> webhelyet.
- (Προαιρετικά) Τα πίσω περιφερειακά στηρίγματα εάφους πωλούνται ξεχωριστά. Για περισσότερες πληροφορίες, ανατρέξτε στην ηλεκτρονική διεύθυνση <http://www.europe.creative.com>



EN English

Specifications

Creative GigaWorks ProGamer G500
Satellite speaker:
36 watts RMS per channel
Centre Satellite Speaker:
36 watts RMS
Subwoofer:
130 watts RMS
Signal-to-Noise Ratio:
85dB
Frequency Response:
35Hz - 20kHz

Important Notice

The serial number for your Creative GigaWorks ProGamer G500 is located on the subwoofer. Please write this number down and keep it in a secure place.

FI Suomi

Tekniset tiedot

Creative GigaWorks ProGamer G500
Satelliittikaiutin:
36 wattia RMS/kanava
Keskuskautin:
36 wattia RMS
Subwoofer:
130 wattia RMS
Signaali-kohinasuhde:
85dB
Taajuualue:
35–20 000 Hz

Tärkeä huomautus
Creative GigaWorks ProGamer G500:n sarjanumero on subwoofer-kaluttimessa. Kirjoita tämä numero ylös ja säilytä se huolellisesti.

FR Français

Spécifications

Creative GigaWorks ProGamer G500
Haut-parleur satellite:
36 watts RMS par canal
Satellite central:
36 watts RMS
Caisson de basse:
130 watts RMS
Rapport signal/bruit:
85dB
Réponse en fréquence:
35Hz - 20kHz

Avis important

Le numéro de série de votre GigaWorks ProGamer G500 de Creative se trouve sur le caisson de basses. Veuillez prendre ce numéro en note et le conserver en lieu sûr.

SV Svenska

Uppgifter

Creative GigaWorks ProGamer G500
Satelliittihögtalare:
36 Watt effektivvärde per kanal
Centersatelliittihögtalare:
36 Watt effektivvärde
Subwoofer:
130 Watt effektivvärde
Signal/störingsförhållande:
85dB
Frekvensområde:
35Hz till 20kHz

Viktigt meddelande
Serienumret för din Creative GigaWorks ProGamer G500 hittar du på subwoofern. Noter nummeret ned, og oppbevar det et sikkert sted.

DE Deutsch

Technische Daten

Creative GigaWorks ProGamer G500
Satellitenlautsprecher:
36 Watt RMS pro Kanal
Satellit Center:
36 Watt RMS
Tiefenlautsprecher:
130 Watt RMS
Rauschabstand:
85dB
Frequenzgang:
35Hz bis 20kHz

Wichtiger Hinweis

Die Seriennummer des Creative GigaWorks ProGamer G500 befindet sich auf dem Subwoofer. Notieren Sie diese Nummer, und bewahren Sie sie an einem sicheren Ort auf.

DA Dansk

Specifikationer

Creative GigaWorks ProGamer G500
Satelliittihögtalare:
36 Watt RMS pr. kanal
Midterste satellitt:
36 Watt RMS
Subwoofer:
130 Watt RMS
Signal/støjforhold:
85dB
Frekvensrespons:
35Hz til 20kHz

Vigtig meddelelse
På Creative GigaWorks ProGamer G500 er serienummeret anbragt på subwooferen. Noter nummeret ned, og opbevar det et sikkert sted.

IT Italiano

Specifiche tecniche

Creative GigaWorks ProGamer G500
Altoparlante satellite:
36 Watt RMS
Satellite centrale:
36 Watt RMS
Subwoofer:
130 Watt RMS
Rapporto segnale-rumore (SNR):
85dB
Risposta frequenza:
da 35Hz a 20kHz

Avviso importante

Il numero di serie di Creative GigaWorks ProGamer G500 è situato sul subwoofer. Annotare questo numero e conservarlo in un posto sicuro.

CZ Česky

Specifikace

Creative GigaWorks ProGamer G500
Satellitní reproduktor:
RMS 36 W na kanál
Centrální terminál satelit:
RMS 36W
Basový reproduktor (Subwoofer):
RMS 130W
Odstup signál/šum:
85dB
Frekvencní rozsah:
35Hz až 20kHz

Důležité upozornění
Sériové číslo zařízení Creative GigaWorks ProGamer G500 je umístěno na subwooferu. Toto číslo si poznamenejte a uložte je na bezpečném místě.

ES Español

Especificaciones

Creative GigaWorks ProGamer G500
Altavoz auxiliar:
36 vatios de carga eficaz por canal
Altavoz satélite central:
36 watt RMS
36 vatios de carga eficaz
Altavoz de graves:
130 vatios de carga eficaz
Relación de señal a ruido:
85dB
Respuesta de frecuencias:
35Hz a 20kHz

Aviso importante

El número de serie para Creative GigaWorks ProGamer G500 se encuentra en el altavoz de graves. Anote este número y guárdelo.

PL Polski

Specyfikacje

Creative GigaWorks ProGamer G500
Głośnik satelitarny:
RMS 36 W na kanał
Centralny terminal satelita:
RMS 36W
Głośnik niskotonowy (Subwoofer):
RMS 130W
Stosunek sygnał/szum:
85dB
pasmo przenoszenia:
35Hz do 20kHz

Ważna informacja
Numer seryjny głośnika Creative GigaWorks ProGamer G500 jest podany na głośniku niskotonowym. Numer ten należy zapisać i przechowywać w bezpiecznym miejscu.

NL Nederlands

Specificaties

Creative GigaWorks ProGamer G500
Satellietsluidspreker:
36 watt RMS per kanaal
Satelliet midden:
36 watt RMS
Subwoofer:
130 watt RMS
Signaal/ruisverhouding:
85dB
Frequentieweergave:
35Hz tot 20kHz

Belangrijke kennisgeving

U vindt het serienummer voor uw Creative GigaWorks ProGamer G500 op de subwoofer. Noteer dit nummer en bewaar het op een veilige plaats.

RU Русский

Технические параметры

Creative GigaWorks ProGamer G500
Сателлитный громкоговоритель:
36 Вт эфф на канал
Центральный динамик:
36 Вт эфф
Низкочастотный громкоговоритель:
130 Вт эфф
Отношение сигнал/шум:
85дБ
Диапазон воспроизводимых частот:
от 35Гц до 20кГц

Важная информация
Серийный номер вашей системы Creative GigaWorks ProGamer G500 указан на низкочастотной колонке. Запишите этот номер и храните в надежном месте.

PT Português

Especificações

Creative GigaWorks ProGamer G500
Coluna satélite:
36 watts RMS por canal
Satélite central:
36 watts RMS
Subwoofer:
130 watts RMS
Relação sinal/ruído:
85dB
Resposta de frequência:
35Hz a 20kHz

Aviso importante

O número de série do sistema de colunas Creative GigaWorks ProGamer G500 está localizado no subwoofer. Anote este número e guarde-o em local seguro.

HU Magyar

Műszaki adatok

Creative GigaWorks ProGamer G500
Szatellit hangszóró:
36 W RMS csatornánként
Középső szatellit hangszóró:
36 watt (RMS)
Mélyugárzó:
130 watt (RMS)
Jel/zaj arány:
85dB
Frekvencia tartomány:
35 Hz - 20 kHz

Fontos
Creative GigaWorks ProGamer G500 rendszerének sorozatszám a mélyugárzóon található. Írja fel ezt a számot, és tartsa biztos helyen.

NO Norsk

Spesifikasjoner

Creative GigaWorks ProGamer G500
Satelliittihögtalare:
36 W RMS per kanal
Midtre satellitt:
36 W RMS
Subwoofer:
130 W RMS
Signalstøyfrekvens:
85dB
Frekvensgang:
35Hz til 20kHz

Viktig merknad


Serienummeret for Creative GigaWorks ProGamer G500 finnes seg på subwooferen. Skriv ned dette nummeret, og oppbevar det på et sikkert sted.

EL Ελληνικά



Προδιαγραφές

Creative GigaWorks ProGamer G500
Περιφερειακό ηχείο:
36 watt RMS ανά κανάλι
Κεντρικό περιφερειακό ηχείο:
36 watt RMS
Subwoofer:
130 watt RMS
Αναλογία σήματος-παραβόλων:
85dB
Ανταπόκριση συχνότητας:
35Hz - 20kHz
12V AC 2.9A.

Σημαντική σημείωση
Ο σειριακός αριθμός του Creative GigaWorks ProGamer G500 βρίσκεται επάνω στο subwoofer. Σημειώστε τον αριθμό αυτόν και φυλάξτε τον σε ασφαλές μέρος.



For placement in front of a monitor



For placement on top of a monitor

